

Swab Sizes by Manufacturer Photographic Solutions

Make	Model	Sensor Type	Notes	Sensor Swab Type	Swab Width (mm)
CANON					
Canon	EOS M	CMOS		2	17
Canon	EOS 1000D	CMOS	Rebel XS	2	17
Canon	EOS 1100D	CMOS	Rebel T3	2	17
Canon	EOS 1200D	CMOS	Rebel T5i	2	17
Canon	EOS 100D up to & including 700D	CMOS		2	17
Canon	EOS 6D	CMOS		3	24
Canon	EOS 7D; M II	CMOS		2	17
Canon	EOS 5D	CMOS		3	24
Canon	EOS 5D Mk II ; 5D Mk III	CMOS		3	24
Canon	EOS D30	CMOS		2	17
Canon	EOS D60	CMOS		2	17
Canon	EOS-1D	CCD		1	20
Canon	EOS-1D Mark II	CMOS		1	20
Canon	EOS-1D Mark II N	CMOS		1	20
Canon	EOS-1D Mark III	CMOS		1	20
Canon	EOS-1D Mark IV	CMOS		1	20
Canon	EOS-1Ds;1DS Mark II; 1DS Mark III	CMOS		3	24
Canon	EOS-1DX	CMOS		3	24
Canon	EOS 10D;20D;30D;40D;50D;60D;70D	CMOS		2	17
CONTAX					
Contax	N Digital	CCD		3	24
FUJI					
Fujifilm	Finepix S1;S2;S3;S5 Pro	CCD		1	20
Fujifilm	X-A1	CMOS		2	17
Fujifilm	X-Pro1	CMOS		2	17
Fujifilm	X-E1	CMOS		2	17
Fujifilm	X-E2	CMOS		2	17
Fujifilm	X-M1	CMOS		2	17
Fujifilm	X-T1	CMOS		2	17
KODAK					
Kodak	DCS SLR/c	CMOS	No AA Filter	3	24
Kodak	DCS SLR/n	CMOS	No AA Filter	3	24
Kodak	DCS 14n	CMOS	No AA Filter	3	24
Kodak	DCS620;620X;760	CCD		1	20
KONICA MINOLTA					
Konica Minolta	Maxxum 5D & 7D	CCD		2	17
LEICA					

Make	Model	Sensor Type	Notes	Sensor Swab Type	Swab Width (mm)
Leica	M8	CCD	No AA Filter	1	20
Leica	M9	CCD	No AA Filter	3	24
Leica	M-Monochrom	CCD	No Col Filter	3	24
Leica	M-E 220	CCD		3	24
Leica	M 240	CMOS		3	24
NIKON					
Nikon	D1	CCD		2	17
Nikon	D100	CCD		2	17
Nikon	Df	CMOS		3	24
Nikon	D1H;D1X	CCD		2	17
Nikon	D200	CCD		2	20
Nikon	D300/300s	CMOS		1	20
Nikon	D300s	CMOS		1	20
Nikon	D2H	JFET		1	17
Nikon	D2Hs	JFET		1	17
Nikon	D2X/s	CMOS		1	20
Nikon	D3/D3s	CMOS		3	24
Nikon	D3X	CMOS		3	24
Nikon	D4, D4s	CMOS		3	24
Nikon	D40/40X/50/60/70/70s	CCD		2	17
Nikon	D600	CMOS		3	24
Nikon	D610	CMOS		3	24
Nikon	D700/750	CMOS		3	24
Nikon	D800/800e	CMOS		3	24
Nikon	D810	CMOS	No OLPF	3	24
Nikon	D80	CCD		2	17
Nikon	D90	CMOS		2	17
Nikon	D3000/3100/3200	CCD		2	17
Nikon	D5000;5100;5200;5300	CMOS		2	17
Nikon	D7000;7100;7200	CMOS		2	17
Nikon	J1;S1;V1;V3	CMOS	CX Format		14
OLYMPUS					
Olympus	E1;E3;E5;E30	CCD	4/3"	2	17
Olympus	E300; E330	CCD	4/3"	2	17
Olympus	E400; 410;420;450	CCD	4/3"	2	17
Olympus	E500; 510;520	CCD	4/3"	2	17
Olympus	E600; 620	NMOS	4/3"	2	17
Olympus	PEN E-P1;P2;P3;P5	NMOS	4/3"	2	17
Olympus	PEN E-PL1/s;PL2;PL3;PL5	CMOS	4/3"	2	17
Olympus	PEN-E-PM1 / M2	CMOS	4/3"	2	17
Olympus	OM-D E-M10	CMOS	4/3"	2	17
Olympus	OM-D E-M5	CMOS	4/3"	2	17
Olympus	OM-D E-M1	CMOS	4/3"	2	17
PANASONIC					
Panasonic	DMC-GF1;GF2;GF3;GF5;GF6	CMOS	4/3"	2	17

Make	Model	Sensor Type	Notes	Sensor Swab Type	Swab Width (mm)
Panasonic	DMC-L1; L10	NMOS	4/3"	2	17
Panasonic	DMC-G1;G2;G3;G5;G6	CMOS	4/3"	2	17
Panasonic	DMC-GM1; G10	CMOS	4/3"	2	17
Panasonic	DMC-GX1; GX7	CMOS	4/3"	2	17
Panasonic	DMC-GH1; GH2; GH3	CMOS	4/3"	2	17
PENTAX					
Pentax	*ist DL	CCD		2	17
Pentax	*ist DS	CCD		2	17
Pentax	*ist D	CCD		2	17
Pentax	K3;K5;K7	CMOS		2	17
Pentax	K-5 II /s	CMOS		1	20
Pentax	K-r	CMOS		2	17
Pentax	K-x	CMOS		2	17
Pentax	K10D	CCD		2	17
Pentax	K100D / Super / K110D	CCD		2	17
Pentax	K20D; K30; K50	CMOS		2	17
Pentax	K200D	CCD		2	17
Pentax	K500	CMOS		2	17
Pentax	K2000 / K-m	CCD		2	17
Pentax	K-01	CMOS		2	17
Pentax	Q	CMOS	1 2/3"	Call	Just Ltd
Pentax	Q7	CMOS	1 1/7"	Call	Just Ltd
Pentax	645Z	CMOS		Call	Just Ltd
SAMSUNG					
Samsung	GX10	CCD		2	17
Samsung	GX20	CMOS		2	17
Samsung	NX5	CMOS		2	17
Samsung	NX10;NX11;NX20;NX30	CMOS		2	17
Samsung	NX100;NX200;NX210;NX300	CMOS		2	17
Samsung	NX1000	CMOS		2	17
Samsung	NX1100	CMOS		2	17
Samsung	NX2000	CMOS		2	17
Samsung	NX Mini	CMOS	1"	Call	Just Ltd
SIGMA					
Sigma	SD1;SD1 Merrill;SD14;SD15	CMOS	Foveon	2	17
Sigma	SD9 & SD10	CMOS	Foveon	1	20
SONY					
Sony	SLT A33;35/37/55/57/58/65/77	CMOS		2	17
Sony	SLT A99	CMOS		3	24
Sony	A100/200/230/290/300/330/350/380/390/	CCD		2	17
Sony	A450/500/550/560/580/700	CMOS		2	17
Sony	A-500	CMOS		2	17
Sony	A850/900	CMOS		3	24
Sony	A6000	CMOS		2	17
Sony	A7/R & A7/R ii	CMOS		3	24
Sony	77 II	CMOS		2	17
Sony	NEX3/3N/C3/5/5N/7	CMOS		2	17